



TECH TIPS

*Presented by Mallory Technical Department
216-688-8300 Ext: 5*

TECH TIP 121605

When using a Mallory 110 or 140 electric fuel pump with a bypass style regulator, be sure to remove the spring from the pump and install the bypass spacer that is included with the regulator.

TECH TIP 120905

A common call that the tech department gets is with distributor grounding. It is imperative that all Mallory 3 wire distributors use an engine ground, not a chassis or firewall. Aluminum heads and intake manifold are not adequate grounds. Be sure to use block ground.

TECH TIP 111105

When removing or installing a distributor cap, make sure you lower the cap straight down onto the distributor and hold it steady while tightening it in place. Sliding the cap on from the side will damage the carbon tip.

TECH TIP 102805

Unilite and MBI distributors have a brown ground wire coming from the 3 wire pigtail harness. Make sure this goes to a good solid ground like the engine block, or chassis. The firewall, fenders or valve covers are not good grounding spots.