

# INTRODUCING THE NEW MALLORY MARINE

## THE NEW MALLORY MARINE PART NUMBER SYSTEM

The NEW Mallory Marine part numbers consist of 6 digits and are grouped by product classification.

Typical part number:

**9-1 0000**  
↑ ↑ ↑  
**A B C**

A. The first digit for Mallory Marine is a 9-, this is an internal identifier that indicates this is a Marine product.

B. The second digit indicates the product classification of the part. The classification list is as follows:

1 = electrical system products	Red
2 = ignition system products	Orange
3 = fuel system products	Yellow
4 = cooling system products	Light Green
5 = engine system products	Green
6 = gaskets, gasket sets	Light Blue
7 = drive system products	Dark Blue
8 = oil & lubricants	Purple
9 = to be announced	Teal

C. The last four digits are unique for each product and in many cases the third digit will be related to a specific OEM.

We hope this will assist you to quickly learn and understand our new part numbers so using Mallory Marine Products will be easier than ever.



# TABLE OF CONTENTS

## ACCESSORIES / MISCELLANEOUS PAGE

Apparel	4-5
Service Manuals	6-9
Service Tools	10
Test Equipment	14

## OILS & LUBRICANTS PAGE

Engine Oil, TC-W3 Two Cycle	11
Engine Oil, FC-W 4-Stroke	11
Fuel Stabilizer	13
Fogging Oil	13
Gear Lube	12
Gear Lube Pumps	14
Grease Guns	13
Oil Absorbent Pads	14

## OUTBOARD ELECTRICAL PARTS PAGE

Alternators	21
Emergency Cut-off Switch	15
Key Switch	15
Relays	16
Rectifiers	22
Solenoids	15-16
Starters	18-19
Stators	36
Trim Motors & Pumps	24-25
Valve Body, trim pump	25
Voltage Regulators	22

## OUTBOARD IGNITION PARTS PAGE

Contact Sets	27
Condensers	27
Emergency Cut-off Switch	15
Ignition Coils	29
Ignition Switch	15
Powerpacks	32-33
Spark Plug Leads	26
Stators	36
Switchboxes	34-35
Tune-Up Kits	27

## OUTBOARD FUEL SYSTEM PARTS PAGE

Carburetor Kits	45-51
Carburetor Floats	45
Fuel Connectors	39
Fuel Filters	40-43
Fuel Pumps	55
Fuel Pump Repair Kits	53-55
Hose Barbs	39
Needle Valves & Seats	45,48
Throttle Position Indicator	55

## OUTBOARD COOLING SYSTEM PARTS PAGE

Grommets	64
Impellers	59-61
Impellers Keys	64-65
Motor Flushing device	56
Thermostats	56
Thermostat Kits	56
Water Pump Bases	62
Water Pump Housings	62-67
Water Pump Cups	63
Water Pump Wear Plates	63
Water Pump Kits	65-68
Water Tube Guide	65
Wear Plates	63

## OUTBOARD INTERNAL ENGINE PARTS PAGE

Air Filter	78
Bearings, wrist pin	80-81
Bearings, connecting rod	80-81
Bearings, main	80-81
Connecting Rods	82
Circlips	83-89
O-Rings	92-93
Oil Filters	78
Oil Seal	92-93
Pistons	83-89
Piston Rings	83-89
Rod Bolts	82

## OUTBOARD GASKETS & GASKET SETS PAGE

Air Box Gaskets	98-119
Base Gaskets	94-116
Carburetor Gaskets	94-116
Drain Plug Gaskets	101-116
Divider Plate Gaskets	107
Exhaust Gaskets	99-107
Fuel Pump Gaskets	98-106
Head Gaskets	94-115
Impeller Gaskets	101-116
Intake Gaskets	98-107
O-Ring, Cylinder Head	97, 106
O2 Sensor Gasket Kit	116
Powerhead Gasket Sets	95-119
Reed Block Gaskets	98-107
Shift Cover Gaskets	101
Thermostat Gaskets	100-116
Water Jacket Gaskets	99-107

## OUTBOARD LOWER UNIT PARTS PAGE

Bearings	134
Bearing Carriers	136
Bushing, Shift Shaft	134
Cotter Pins	138
Drain/Fill Screws	135-137
Oil Seals	129-130
O-Rings	131-133
Pinion Nut	134
Prop Nuts	137-138
Prop Nut Kits	136-137
Prop Shaft	134
Prop Spacers	137-138
Seal Kits	120-128
Spanner Nuts	135
Stainless Steel Locknuts	135
Tab Washers	137
Trim Hoses	135
Washer, Pinion Nut	134

## INBOARD & STERNDRIVE ELECTRICAL PARTS PAGE

Alternators	148-149
Relays	139-143
Reservoirs, Power Trim	153
Solenoids	139-143
Starters	144-147
Trim Motors & Pumps	153-154

# TABLE OF CONTENTS

## INBOARD & STERNDRIVE IGNITION PARTS PAGE

Condensers	155
Contact Sets	155
Ignition Coils	167-169
Ignition Modules	169
Ignition System, Complete	182
Distributor Caps	159-167
Distributors	182-185
Electronic Conversion Kits	170
Rotors	155-167
Sensors, Ignition	169
Shift Assist Modules	171
Spark Plug Wire Sets	173-180
Tune-Up Kits	157-166
Wire Markers	171
Wire Separators	171

## INBOARD & STERNDRIVE FUEL SYSTEM PARTS PAGE

Carburetor Kits	190-198
Carburetor Floats	193-198
Carburetors, New	200-204
Carburetors, Remanufactured	205-207
Coolant & Temp Sensors	209-211, 241
EFI throttle body kit	214
EFI Multi-Port System	213-214
Flame Arrestors	199-200
Fuel Filters & Kits	186-189
Fuel Injectors & Kits	207-211
Fuel Pressure Regulators	208-211
Fuel Pumps	215-225
IAC Motors	208-211
Knock Sensors	209-211
MAP Sensors	208-211
Throttle Position Sensors	208-211
Water Separating Filters	186-189

## INBOARD & STERNDRIVE COOLING SYSTEM PARTS PAGE

Base, Water Pump	228
Cup, Water Pump Housing	229
Drain Cock	240
Drain Elbow	240
Exhaust Flapper	240
Hose barb	240
Hose Kits	240
Hose, Circulating Pump	241
Housings, Water Pump	228-229
Impellers	227-228
Impeller Kits	227
Thermostats	231-239
Thermostat Housings	240
Thermostat Kits	231-239
Water Pump, Engine Circulating	226
Water Pump Kits	228

## INBOARD & STERNDRIVE ENGINE PARTS PAGE

Air Filters	245
Crankcase Filters	245
Engine Couplers - see drive parts	
Engine Primer	246
Freeze Plug Kits	248
Flywheels	247
Mount, engine	248
Oil Filters	242-245
Valve Covers	246

## INBOARD & STERNDRIVE GASKETS & GASKET SETS PAGE

Carb Mounting Gaskets	249-250
Cylinder Head Gaskets	251
Exhaust Gaskets & Sets	252-253
Intake Gaskets & Sets	253-254
Gasket Sets, Overhaul	252
Oil Pan Gaskets & Sets	255
Outdrive Mounting Gasket Sets	250-251
Thermostat Gaskets	249
Valve Cover Gaskets	254-255

## INBOARD & STERNDRIVE DRIVE SYSTEM PARTS PAGE

Anchor Pin Kits	268
Ball Gears & Kits	269
Bearings	267
Bellows	259-260
Bellows Kits	259-260
Bushings, Pivot Pin	268
Bushings, Shift Shaft	267
Center Socket	265
Check Valve Kit	266
Drain/Fill Screw	269
Drive Shafts	266-267
Electric Shift Cable	263
Engine Couplers	264
Exhaust Tubes	259-261
Gear Housings, Lower	267
Gear Housings, Upper	266
Gear Repair Kits	266-267
Gimbal Bearings	265
Hose, Water Intake	259-260
Oil Seals	272-273
O-Rings	274-277
Pinion Nut	267
Prop Shafts	267
Prop Nut	270
Prop Nut Kits	270
Prop Spacer	270
Ring, Upper Unit Spacer	266
Seal Kits	271
Shift Arm	263
Shift Cable	262-263
Shift Cable Kits	262-263
Shift Cable Slide	263
Shift Shafts	267
Shift Shaft Bushings	267
Shift Slide Screw	263
Spanner Nut	266
Stainless Steel Lock Nut	268
Tab Washer	270
Top Cover	266
Trailer Clips	270
Transom Seal	260
Transom Seal Kits	260-262
Trim Bushings	268
Trim Hoses	256-258
Universal Joint	265
Yokes	265

## QUICK REFERENCE GUIDE PAGE

Carburetor Number to Carburetor Kit Interchange	278-289
Distributor Number service parts guide	290-293
OEM interchange	294-354
Part number to page number guide	355-388